



Component Specification

C00540

M80 & M83 Series Rectangular Connectors
November 2022

SECTION	TITLE	PAGE
1	Description of Connectors and Intended Applications	2
2	Ratings	2
Appendix 1	Contact Orientations	6
Appendix 2	Coax Contact Details (Datamate Mix-Tek)	9
Appendix 3	Gauges (Low Frequency Contacts)	12
Appendix 4	Test for Latch Integrity (Datamate L-Tek)	13
Appendix 5	Instructions for the use of Connectors fitted with Jackscrews	14
Appendix 6	Instructions for the use of 101Lok Fixings	15







1. **DESCRIPTION OF CONNECTOR AND INTENDED APPLICATION**

A range of 2mm pitch male and female rectangular, fully shrouded unsealed connectors with replaceable contacts for interconnecting board to board, cable to board and cable to cable. The range covers 2 to 96 ways, in various application methods. Female connectors are available for crimp, vertical throughboard and surface mount termination. Male connectors are available for crimp, vertical or horizontal (90°) throughboard and surface-mount termination. Pre-cabled contacts and cable assemblies are also available in various options.

The connectors are provided with a range of contact terminations (as shown in Appendix 1) that are gold or tin plated. The contact zone of a gold plated contact is hard acid gold of 98% purity.

The connector is intended for use as a low voltage connector in high packing density electronic equipment. The connector is polarised to prevent mis-matching and can be produced with a latching feature (L-Tek) or in a jackscrew (J-Tek) format, with or without board mounting.

L-Tek and J-Tek connectors are available with low-frequency (LF) contacts, while mixed technology (Mix-Tek) connectors are also available with jackscrews, with a choice of power or coax contacts.

NOTE: Some connector styles are available manufactured and tested to BS9525 F0033. All other connectors in the range are designed to the same specification. For cable assembly specifications see Component Specification CO49XX (where XX is latest issue).

2. **RATINGS**

2.1. Low-Frequency Signal Contacts

2.1.1. Current Rating

Standard Signal Contact:
One contact per connector is electrically loaded, 25°C ambient
One contact per connector is electrically loaded, 85°C ambient 2.6A max
Current per contact through all contacts, 25°C ambient
Current per contact through all contacts, 85°C ambient
T-Contact:
One contact per connector is electrically loaded, 25°C ambient
One contact per connector is electrically loaded, 85°C ambient 6.5A max
Current per contact through all contacts, 25°C ambient
Current per contact through all contacts, 85°C ambient
Flex Circuit Assembly:
Current per individual track, 25°C ambient

2.1.2. Other Electrical Characteristics

Working Voltage (at 1,013mbar, sea level):	
Pre-Cabled Contacts & Cable Assemblies	300V DC or AC peak
Others	800V DC or AC peak
Voltage Proof (at 1,013mbar, sea level)	1,200V DC or AC peak
Contact Resistance:	
Initial	20m Ω max
After Conditioning	25mΩ max
Insulation resistance:	
Initial	1,000M Ω min
Hot After Conditioning	100MΩ min
Creepage Path contact-to-contact	0.35mm min
Air Gap contact-to-contact	0.35mm min



2.1.3. Environmental Characteristics

Environmental Classification	55/125/56 Days	at 95% RH
Operating Temperature Range	55°C to +125°C	•
Low Air Pressure Severity (only one contact is el	ectrically loaded)300 mbar (9,14	4m/30,000ft)
The connector will function correctly using a		ature and
low air pressure down to 300mbar (altitude	of 9,144m/30,000ft) up to 360V DC.	
Salt Spray:		
L-Tek		
	6.5/7.2pH @ 40°C, 93% Humidity for 66 he	ours)
J-Tek & Mix-Tek	. EIA364 Test Procedure 26 condition A (5%	Solution,
	6.5/7.2pH @ 35°C, 95% Humidity for 96 ha	วบrs

2.1.4. Vibration, Shock, Bump

In all cases, mating jackscrews or latches are fully utilized.

Standard	Signal	Contact:
----------	--------	----------

Standard Signal Contact:	
Vibration Severity (10G test)	10 Hz to $2,000$ Hz, 0.75 mm, 98 m/s 2 (10 G), $duration 6 hours$
Vibration Severity (20G test)	10Hz to 81.73Hz, 1.5mm peak-to-peak; 57.55Hz to 2,000Hz,
	196.2m/s² (20G), duration 2 hours
Shock Severity	981m/s² (100G), 18 shocks total
Bump Severity	390m/s² (40G), 4,000±10 bumps
T-Contact:	·
Vibration Severity	10Hz to 13.6Hz, 35mm peak-to-peak, 13.6Hz to 41.6Hz,
•	1.5mm peak-to-peak, 41.6Hz to 2,000Hz, 392.4m/s² (40G),
	duration 6 hours
Shock Severity	981m/s² (100G)

2.1.5. Mechanical Characteristics

Clip Retention in Body	
High Temperature, Long Term (current as in 2.1.1.) High Temperature, Short Term (no electrical load) Contact Retention in Housing Contact Replacement in Housing (Male Crimp Jackscrew) Durability:	250 hours at 125°C 10N min
Standard Signal Contact	1,000 operations 0.2N min
M80 Standard Signal Contact	2.0N max 1.0N max 4.0N max
M80 Standard Signal Contact	0.2N min 0.2N min 0.5N min up to 2 times max



2.1.6. Wire Termination Range

Recommended Wire TypeSee Component Specification CO49XX (latest issue)

Crimp Type	AWG Wire Size	Qty & Nominal diameter (mm) of strands	Minimum pull-off force	M22520/2-01 Crimp tool setting	Max. insulation diameter
Extra	32	7/0.08	4.0N	4	
Small	30	1/0.25	7.0N	4	Ø0.75mm
Bore	28	7/0.12	12.5N	5	
المصا	28	7/0.12	12.5N	6	
Small Bore	26	7/0.15	25.0N	6	
Боге	24	7/0.2	44.0N	6	Ø1.10mm
Large Bore	22	19/0.15	50.0N	6	1.10111111
T-Contact	22	19/0.15	50.0N	6	

2.2. Coax Contacts

2.2.1. Electrical Characteristics

Impedance	50Ω
	6GHz (Also dependent on cable type or board layout)
VSWR (Voltage Standing Wave Ratio):	
M80-310	1.19 + (0.04 x Frequency) GHz max
Others	1.05 + (0.04 x Frequency) GHz max
	180V AC at 500mA
Voltage Proof (at 1,013mbar, sea level)	1,000V AC _{rms}
Contact Resistance	6m Ω max
Insulation Resistance (at 250V rms)	10 ⁶ ΜΩ

2.2.2. Wire Termination Range

Cable Type	Max. Insulation Diameter	Compatible contacts
RG 178	Ø2.0mm	M80-305, M80-308, M80-315, M80-318
RG 174		
RG 179	Ø2.7mm	M80-307, M80-309, M80-317, M80-319
RG 316		
UT 047	Ø1.2mm (outer conductor)	M80-310

2.2.3. Mechanical Characteristics

Durability	. 500 operations
Insertion Force (per contact, using mating contact, no fixings)	. 20.0N max
Withdrawal Force (per contact, using mating pin, no fixings)	. 0.5N min
Contact Wipe	. 1.30mm min
Contact Replacement in Housing	. 5 times max



2.3. Power Contacts

2.3.1. Electrical Characteristics

Current Rating:	
M80-3XX contact	20A max
M80-PXX contact	40A max
Working Voltage (at 1,013mbar, sea level)	800V DC or AC peak
Voltage Proof (at 1,013mbar, sea level)	1,200V DC or AC peak
Contact Resistance	•

2.3.2. Wire Termination Range

Recommended Wire Type See Component Specification CO49XX (latest issue)

AWG	Current Rating of cable	Compatible contacts
10	40A max	M80-PF5, M80-PM5
12	20A max	M80-325, M80-335, M80-32A
14	15A max	M80-326, M80-336, M80-32B
16	10A max	M80-327, M80-337, M80-32C
18	8A max	M80-328, M80-338
20	5A max	M80-329, M80-339

2.3.3. Mechanical Characteristics


Durability	00 operations		
High Temperature, Long Term (no electrical load)	000 hours at 150°C		
Insertion Force:			
M80-3XX contact 8.0	ON max		
M80-PXX contact	i.ON max		
Withdrawal force	5N min		
Contact wipe	30mm min		
Contact Replacement in Housing 5 t	times max		




APPENDIX 1 - CONTACT ORIENTATIONS

These diagrams show pin numbers with reference to the polarization feature. They represent male connectors, shown looking onto the contact face. For female connectors looking on the mating face, the numbering will be mirrored.

A1.1. Datamate L-Tek - Single Row



A1.2. Datamate L-Tek - Double Row







APPENDIX 1 - CONTACT ORIENTATIONS (continued)

These diagrams show pin numbers with reference to the polarization feature. They represent male connectors, shown looking onto the contact face. For female connectors looking on the mating face, the numbering will be mirrored.

A1.3. Datamate J-Tek - Double Row



A1.4. Datamate J-Tek 3-Row (M83 series)




Only signal contacts (18-contact version shown, others follow the same pattern)




<u>APPENDIX 1 - CONTACT ORIENTATIONS (continued)</u>

These diagrams show pin numbers with reference to the polarization feature. They represent male connectors, shown looking onto the contact face. For female connectors looking on the mating face, the numbering will be mirrored.

A1.5. Datamate Mix-Tek



A1.6. Damatate Mix-Tek 3-Row (M83 Series)




Signal and special contacts




<u>APPENDIX 2 – COAX CONTACT DETAILS</u>

A2.1. Coax Contact Interface Dimensions




A2.2. Coax Contact Assembly Instructions - M80-305/307, M80-315/317


1) Strip cable to dimensions shown against relevant part (see appropriate technical drawing).




2) Identify pieces of coax connector to be assembled.




3) Slide sleeve onto cable past stripped area.




4) Crimp contact to end of cable inner conductor.



5) Insert cable and contact into coax body from back end – make sure that the braid goes outside and over the end section.



6) Slide sleeve back over the end of the coax body and the braid. Crimp into place on the cable insulation, using a hexagonal crimping tool.







APPENDIX 2 - COAX CONTACT DETAILS (continued)

A2.3. Coax Contact Assembly Instructions – M80-308/309, M80-318/319.


1) Strip cable to dimensions shown against relevant part (see appropriate engineering drawings).




2) Identify pieces of coax connector to be assembled.




3) Slide sleeve onto cable past stripped area.



4) Push the cable and sleeve into the body, as far as it will go. The cable inner conductor will be visible through the hole in the back of the coax body, and should go into the slot in the inner contact. Make sure that the braid goes outside and over the end section.



5) Solder the cable inner conductor to the body inner contact. When cool, place the insulator inside the top, and press the cover into place. Slide the sleeve up to meet the coax body, and hexagonal crimp in place.







APPENDIX 2 - COAX CONTACT DETAILS (continued)

A2.4. Coax Contact Assembly Instructions – M80-310.


Strip cable to dimensions shown against relevant part (see appropriate engineering drawings).




2) Identify pieces of coax connector to be assembled.



3) Push the cable into the body, as far as it will go. The cable inner conductor will be visible through the hole in the back of the coax body, and should go into the slot in the inner contact.



4) Solder the cable inner conductor to the body inner contact. When cool, press the cover into place (with the insulator on the inside of the contact). Solder the cable outer conductor to the contact body.






APPENDIX 3 - GAUGES (LOW FREQUENCY)


NOTES:

- 1. Material = Steel to BS1407 or equivalent.
- 2. Gauging surfaces to be hardened/ground to 650 H.V. minimum.
- 3. These gauges to be used for testing fully assembled components only.
- 4. Ultimate wear limit of 0.005mm is allowable on gauging diameters.
- 5. Loading force (Bending moment) to give 0.002Nm (Test prod only).
- 6. All dimensions are in millimetres.
- 7. For explanation of dimensions, etc. see BS8888.
- 8. Unless otherwise stated, all dimensions are maxima.


A3.1. Test Prod



A3.2. Sizing Gauge




A3.3. Holding Gauge





APPENDIX 4 - TEST FOR LATCH INTEGRITY ON L-TEK

When an unloaded female connector moulding is mated with a latched male connector, and a force of 20N is applied for 10 seconds in the directions shown, there shall be no failure of any part of the latch mechanism.



<u>APPENDIX 5 - INSTRUCTIONS FOR THE USE OF CONNECTORS FITTED WITH</u> JACKSCREWS

Connectors are fitted with jackscrews where it is considered necessary to provide mechanical assistance in ensuring a satisfactory engagement and separation of the connector. This may apply in cases where engagement and separation forces are so high as to prevent satisfactory hand engagement, or where access to connector is restricted. Jackscrews also provide a locking feature, preventing the connector from disengaging under adverse conditions.

To obtain maximum effectiveness from the jackscrew system, the following rules for their use should be observed.

1) The connector with board mount jackscrews should be fixed to the PCB with fixings and tightened to a torque of **21±2cmN**.

Board mount fixings must be fitted before Wave soldering.

Board mount fixings can be fitted before or after reflow soldering, as preferred by customer. If fitted before soldering, check that the fixings remain tight after soldering.

NOTE: Care must be taken when aligning male and female threads, to avoid cross-threading and possible failure of parts.

2) On engaging the two halves of the connector after ensuring correct polarity, lightly push home the floating half until the jackscrews touch. Then, maintaining the pressure, turn one of the floating jackscrews clockwise, until it engages with the fixed screw. Repeat with the other screw.

Then screw in each jackscrew, ensuring even loading by applying a maximum of one turn to each screw in sequence until the connector is bottomed. This will be evident by a sudden increase in the torque required on the screw. This torque should not exceed **23cmN**.

Finger pressure exerted at the centre of the connectors may be required to achieve full engagement of both halves.

NOTE: Care must be taken when aligning male and female threads to avoid cross-threading and possible failure of parts.

3) On disengaging the two halves of the connector turn each of the floating jackscrews anti clockwise. Again, ensure even loading by turning each screw in sequence for a maximum of one turn until the jackscrew disengage. The connector can then be easily pulled apart.

C00540

Component Specification – M80 & M83 Series Rectangular Connectors



APPENDIX 6 - INSTRUCTIONS FOR THE USE OF 101LOK FIXINGS

- 1) Before engaging, ensure that the slot on the fixing head is at right angles to the length of the connector.
- 2) Push the connectors together. Once the connectors are mated, use a screwdriver to push down onto each 101Lok fixing until the spring is compressed. Turn the fixing 101 degrees, and release. The 101Lok fixing should remain partially compressed.
- 3) To disengage, use a screwdriver to push down on each 101Lok fixing until the spring is compressed. Turn the fixing anti-clockwise 101 degrees, and release. The 101Lok fixing will spring back to its uncompressed position.